

# 110 TM


**PALFINGER**

PK110002 SH

020.05100

Lifting capacity diagram PK 110002-SH F

Subject to change, production tolerances have to be taken into account.



8 skud  
3750  
y  
Fyjob.


Symbolic crane figure, indications at 20° main boom position & load arm in horizontal position

For Rope winch load capacity refer to page

Page 020.20100

Subject to change, production tolerances have to be taken into account.

8 stuid horeclarm → Flyjib : 800kg



When using mechanical boom extensions, the loads shown on the charts need to be reduced by the weight of these extensions.

Symbolic crane figure, indications at 20° main boom position & load arm in horizontal position

For Rope winch load capacity refer to page

Page 020.20100